

# AUTOMATIC AWNING FITTING INSTRUCTIONS

Your new Outdoor Auto Awning has been custom built for you from the highest quality materials please follow the installation instructions provided.



- |           |
|-----------|
| End Caps  |
| Head Box  |
| Roller    |
| Guide Arm |
| Base Rail |
| Auto Arm  |
| L Bracket |

**Recommended Screws:**

Timber: 8ga Self Drilling into Timber, button head, Zinc Coated  
 Steel: Self Drilling Screws 8-18 yellow zinc x 12mm, Phillip Drive  
 Brick: Plugs (green), 10ga x 37mm

**Fitting Instructions:**

- Fit head box by fixing end caps to the wall, making sure that head box is level
- Secure Roller into the head box locating the ends into bracket, insert pin end first, then spring end.
- Secure Guide arms - Fit to bottom hole of head box cover.
- Slide Auto arm onto guide arm
- Screw Auto arm onto base rail
- Lower blind to bottom of guide arms
- Slide L bracket onto bottom of guide arms
- Making sure that the guide arms are level, screw L bracket onto the wall

**Note:**

All blinds come with a pull down stick

**Operating Your Blind:**

Operate by tilting base rail back and down toward the window. This will release the auto arm so you can then lower or raise the blind  
 Your blind is now installed and ready. We hope it brings you and your home many years of great functionality and beauty. We thank you for your purchase.